RD-6502

AUDIO/VIDEO RECEIVER

Sherwood

5707-04735-048-0S

Sherwood

OPERATING INSTRUCTIONS

RD-6502

AUDIO/VIDEO RECEIVER

CE

Introduction

ENGLISH

READ THIS BEFORE OPERATING YOUR UNIT

CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN

CAUTION : TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

	This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.
	This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

WARNING : TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

Caution regarding installation

Note : For heat dispersal, do not install this unit in a confined space such as a bookcase or similar enclosure.





Do not block ventilation openings or stack other equipment on the top.

FOR YOUR SAFETY

EUROPE AUSTRALIA	**220 V - 240 V**	Units shipped to Australia are designed for operation on 240 V AC only. To ensure safe operation, the three-pin plug supplied must be inserted only into a standard three-pin power point which is effectively earthed through the normal household wiring. Extension cords used with the equipment must be three-core and be correctly wired to provide connection to earth. Improper extension cords are a major cause of fatalities. The fact that the equipment operates satisfactorily does not imply that the power point is earthed and that the installation is completely safe. For your safety, if in any doubt about the effective earthing of the power point, consult a qualified electrician. PAN-EUROPEAN UNIFIED VOLTAGE All units are suitable for use on supplies 220-240 V AC.

CAUTION

- Leave a space around the unit for sufficient ventilation.
- Avoid installation in extremely hot or cold locations, or in an area that is exposed to direct sunlight or heating equipment.
- Keep the unit free from moisture, water, and dust.
- Do not let foreign objects in the unit.
- The ventilation should not be impeded by covering the ventilation openings with items, such as newspapers, table-cloths, curtains, etc.
- No naked flame sources, such as lighted candles, should be placed on the unit.
- Please be care the environmental aspects of battery disposal.
- The unit shall not be exposed to dripping or splashing for use.
- No objects filled with liquids, such as vases, shall be placed on the unit.
- Do not let insecticides, benzene, and thinner come in contact with the set.
- Never disassemble or modify the unit in any way.

■ Notes on the AC power cord and the wall outlet.

- The unit is not disconnected from the AC power source(mains) as long as it is connected to the wall outlet, even if the unit has been turned off.
- When disconnecting the power cord from the wall outlet, always pull the plug, not the power cord.
- Disconnect the plug from the wall outlet when not using the unit for long periods of time.
- The wall outlet shall be installed near the unit and shall be easily accessible.

Note on recycling

This product's packaging materials are recyclable and can be reused. Please dispose of any materials in accordance with the local recycling regulations.
When discarding the unit, comply with local rules or regulations.
Batteries should never be thrown away or incinerated but disposed of in accordance with the local regulations concerning chemical waste.
This product and the accessories packed together constitute the applicable product according to the WEEE directive except batteries.

CONTENTS

Introduction

• READ THIS BEFORE OPERATING YOUR UNIT **2**
• ACCESSORIES **3**

System Connections **4**

Front Panel Controls **9**

Remote Controls **11**
• REMOTE CONTROL OPERATION RANGE **12**
• LOADING BATTERIES **12**

Operations

• LISTENING TO A PROGRAM SOURCE **13**
• SURROUND SOUND **16**
• ENJOYING SURROUND SOUND **17**
• LISTENING TO RADIO BROADCASTS **22**
• LISTENING TO RDS BROADCASTS (FM ONLY) **24**
(RDS Tuner (Regional Option for some countries in Europe, etc))
• RECORDING **26**
• OTHER FUNCTIONS **28**

System Setup **29**
• SETTING THE SYSTEM **31**
• SETTING THE INPUT **32**
• SETTING THE SPEAKER SETUP **34**
• SETTING THE CH LEVEL **38**
• SETTING THE PARAMETER **40**

Troubleshooting Guide **42**

Specifications **43**

ACCESSORIES

• 1. Operating Instructions ..... **1 ea**
• 2. Remote Control unit ..... **1 ea**
• 3. Batteries (AAA) ..... **2 ea**
• 4. AM Loop Antenna ..... **1 ea**
• 5. FM Indoor Antenna ..... **1 ea**



ENGLISH

System Connections

- Do not plug the AC input cord into the wall AC outlet until all connections are completed.
- Be sure to observe the color coding when connecting audio, video and speaker cords.
- Make connections firmly and correctly. If not, it can cause loss of sound, noise or damage to the receiver.



1. CONNECTING ANTENNAS

FM Indoor Antenna



- Change the position of the FM indoor antenna until you get the best reception of your favorite FM stations.

FM Outdoor Antenna



- A 75Ω outdoor FM antenna may be used to further improve the reception. Disconnect the indoor antenna before replacing it with the outdoor one.



AM Outdoor Antenna



- Place the AM loop antenna as far as possible from the receiver, TV set, speaker cords and the AC input cord and set it to a direction for the best reception.
- If the reception is poor with the AM loop antenna, an AM outdoor antenna can be used in place of the AM loop antenna.

2. CONNECTING VIDEO COMPONENTS



- The jacks of VIDEO 1 may also be connected to a DVD recorder or other digital video recording component. For details, refer to the operating instructions of the component to be connected.
- The jacks of VIDEO 2 can also be connected to an additional video component such as a cable TV tuner, an LD player or satellite system.

■ **Note :**

- When Sherwood DVD player such as V-768, etc. is connected to the DIGI-LINK jack for system control, you should connect the DVD player to the " VIDEO 2" jacks of this unit.
  Because, if the PLAY button, etc. is pressed on the DVD player, the VIDEO 2 is automatically selected as an input source on this unit. Then playback, etc. starts.

3. CONNECTING AUDIO COMPONENTS

- The TAPE IN/OUT jacks can be connected to audio recording equipment such as a tape deck, an MD recorder, etc.



ENGLISH

4. CONNECTING EXTERNAL INs

• Use these jacks to connect the corresponding analog outputs of 6 CH decoder or DVD player with 6 CH output for Dolby Digital or DTS, etc.
(For details, see the operator's manual of the component to be connected.)



Decoder with 6 channel outputs

5. CONNECTING DIGITAL INs



• The OPTICAL and the COAXIAL DIGITAL OUTs of the components that are connected to CD and VIDEO 1 ~ VIDEO 2 of this unit can be connected to these DIGITAL INs.
• A digital input should be connected to the components such as a CD player, LD player, DVD player, etc. capable of outputting DTS Digital Surround, Dolby Digital or PCM format digital signals, etc.
• For details, refer to the operating instructions of the component connected.
• When making the COAXIAL DIGITAL connection, be sure to use a 75 Ω COAXIAL cord, not a conventional AUDIO cord.
• All of the commercially available optical fiber cords cannot be used for the equipment. If there is an optical fiber cord which cannot be connected to your equipment, consult your dealer or nearest service organization.

■ **Notes :**

• Be sure to make either a OPTICAL or a COAXIAL DIGITAL connection on each component. (You don't need to do both.)

6. CONNECTING DIGI-LINK

• Connect this jack to the DIGI-LINK jack of the external Sherwood component that uses the DIGI-LINK II or III remote control system.



7. CONNECTING SUBWOOFER PRE OUT

• To emphasize the deep bass sounds, connect a powered subwoofer.



8. CONNECTING SPEAKERS

• Be sure to connect speakers firmly and correctly according to the channel(left and right) and the polarity(+ and -). If the connections are faulty, no sound will be heard from the speakers, and if the polarity of the speaker connection is incorrect, the sound will be unnatural and lack bass.
• For installing the speakers, refer to "Speaker placement" on page 8.
• After installing the speakers, first adjust the speaker settings according to your environment and speaker layout.(For details, refer to "SETTING THE SPEAKER SETUP" on page 34.)

Caution :
• Be sure to use the speakers with the impedance of 6 ohms or above.
• Do not let the bare speaker wires touch each other or any metal part of this unit. This could damage this unit and/or the speakers.



9. SWITCHED AC OUTLET

• This outlet is switched on (power-on mode) and off (standby mode) according to power control as follows (Maximum total capacity is 100 W (0.43A)).

Standby mode - Switched AC outlet off
Power-on mode - Switched AC outlet on



10. AC INPUT CORD

• Plug the cord into a wall AC outlet.

Speaker placement

Ideal speaker placement varies depending on the size of your room and the wall coverings, etc. The typical example of speaker placement and recommendations are as follows :

■ **Front left and right speakers and center speaker**
- Place the front speakers with their front surfaces as flush with TV or monitor screen as possible.
- Place the center speaker between the front left and right speakers and no further from the listening position than the front speakers.
- Place each speaker so that sound is aimed at the location of the listener's ears when at the main listening position.

■ **Surround left and right speakers**
- Place the surround speakers approximately 1 meter (40 inches) above the ear level of a seated listener on the direct left and right of them or slightly behind.

■ **Subwoofer**
- The subwoofer reproduces powerful deep bass sounds. Place a subwoofer anywhere in the front as desired.

■ **Notes :**
- When using a conventional TV, to avoid interference with the TV picture, use only magnetically shielded front left and right and center speakers.
- To obtain the best surround effects, the speakers except the subwoofer should be full range speakers.



1. TV or screen
2. Front left speaker
3. Front right speaker
4. Center speaker
5. Subwoofer
6. Surround left speaker
7. Surround right speaker

Front Panel Controls



1. MULTI CONTROL knob (◀/▶)
2. POWER switch
3. REMOTE SENSOR
4. FLUORESCENT DISPLAY
   For details, see below.
5. VIDEO INPUT SELECTOR button
6. AUDIO INPUT SELECTOR button
7. EXTERNAL IN button
8. FM/AM button
9. MASTER VOLUME CONTROL knob
10. HEADPHONE jack
11. SPEAKER indicator
12. SPEAKER button
13. POWER ON/STANDBY button/indicator
14. SURROUND MODE button
15. STEREO button
16. DISPLAY button
17. DIGITAL/ANALOG MODE button
18. SETUP button
19. CHANNEL LEVEL button
20. CONTROL UP/DOWN(▲/▼) buttons
21. MEMORY/ENTER button
22. TUNING UP/DOWN(+/-) buttons
23. PRESET UP/DOWN(+/-) buttons
24. AUX1, 2 IN jacks
    For details, see next page.
25. VIDEO 3 IN jacks
    For details, see next page.

■FLUORESCENT DISPLAY



1. Input, frequency, volume level, operating information, etc.
2. Surround mode indicators
3. AUTO indicator
4. DIGITAL INPUT indicator
5. DIRECT indicator
6. Preset number, sleep time display
7. MEMORY indicator
8. PRESET indicator
9. SLEEP indicator
10. TUNED indicator
11. STEREO indicator
12. RDS indicators
    (Regional option for Europe, etc.)

■ AUX IN JACK

• The AUX 1, 2 IN jacks can be connected to additional audio components such as an MP3 player, etc.

■ **Note :**

• When connecting these jacks to an MP3 player, etc., you should use the stereo mini cord, not a mono mini cord.



■ VIDEO 3 IN JACKS

• The VIDEO 3 IN jacks may be also connected to an additional video component such as a camcorder, video game player, etc.



VIDEO 3 Camcorder, video game player, etc.

Remote Controls



REMOTE CONTROL OPERATION RANGE



- Use the remote control unit within a range of about 7 meters (23 feet) and angles of up to 30 degrees aiming at the remote sensor.

LOADING BATTERIES

1. Remove the cover.



2. Load two batteries ("AAA" size, 1.5 V) matching the polarity.



- Remove the batteries when they are not used for a long time.
- Do not use the rechargeable batteries (Ni-Cd type).

Operations

■ **Note :**

• Before operating this receiver, first set this unit as desired for optimum performance, doing the system setup precedures. (For details, refer to "System Setup" on page 29.)

ENGLISH

LISTENING TO A PROGRAM SOURCE

Before operation

• Enter the standby mode.

• The POWER ON/STANDBY button lights up.
This means that the receiver is not disconnected from the AC mains and a small amount of current is retained to support the operation readiness.
• To switch the power off, push the POWER switch again.
• Then the power is cut off and the POWER ON/ STANDBY button goes off.

1. In the standby mode, turn the power on.



• Each time the POWER ON/STANDBY button on the front panel is pressed, the receiver is turned on to enter the operating mode or off to enter the standby mode.
• On the remote control, press the POWER ON button to enter the operating mode or press the STANDBY button to enter the standby mode.
• In the standby mode, if the INPUT SELECTOR button is pressed, the receiver is turned on automatically and the desired input is selected.

2. Switch the speakers on.

• Then the SPEAKER indicator lights up and the sound can be heard from the speakers connected to the speaker terminals.
• When using the headphone for private listening, press the SPEAKER button again to switch the speakers off.

3. Select the desired input source.



• Each time the “VIDEO” button on the front panel is pressed, the input source changes as follows:
→ VIDEO 1 → VIDEO 2 → VIDEO 3 ┐

• Each time the “AUDIO” button on the front panel is pressed, the input source changes as follows:
→ CD → AUX1 → AUX 2 → TAPE ┐

• Each time the “FM/AM” button is pressed, the band changes as follows:
→ FM ST → FM MONO → AM MONO ┐

■ **When selecting the EXTERNAL IN as desired,**



• "EXT IN" is displayed and 6 separate analog signals from the component connected to this input pass through the tone and volume circuits only and can be heard from your speakers.
• Select the desired input source to cancel the external in function.
• These analog signals can be heard only, not recorded.

When CD, VIDEO 1~2 is selected as an input source

4. Select the digital or the analog input connected as desired.



- Each time this button is pressed, the corresponding input is selected as follows:

→ o(ptical) 1 → c(oaxial) 1 → c(oaxial) 2 →
A(nalog) ←

■Notes :

- WhenTUNER, AUX 1~2, TAPE, EXTERNAL IN or VIDEO 3 is selected as an input source, the analog input is selected automatically.
- When the selected digital input is not connected, the "DIGITAL" indicator flickers and the analog input is automatically selected.
- The selected digital or analog input is automatically assigned to the corresponding input source on the INPUT setup menu. (For details, refer to "SETTING THE INPUT " on page 32.)
- The sound from the component connected to the selected digital input can be heard regardless of the selected input source.

5. Operate the selected component for playback.

- When playing back the program sources with surround sound, refer to “ENJOYING SURROUND SOUND” on page 17.

6. Adjust the (overall) volume.



7. To mute the sound.



- “MUTE” will flicker.
- To resume the previous sound level, press it again.

8. To listen with the headphones.



- Ensure that the SPEAKER button is set to off.
- When listening to a DTS or Dolby Digital program source, if the headphones are plugged in and the SPEAKER button is set to off, it enters the 2CH downmix mode automatically. (For details, refer to “2 CH downmix mode”on page 18.)
- When the EXTERNAL IN is selected as an input source, only front left and front right channel signals can be reproduced through the headphones.

Adjusting the tone (bass and treble)

9. Enter the tone mode.



- The tone mode is displayed for several seconds.

■ **Note :**

- When the EXTERNAL IN is selected as an input source, you can neither select the tone mode nor adjust the tone.

10. Press the CURSOR LEFT(◀)/RIGHT(▶) buttons to select the desired tone mode.



- Each time these buttons are pressed, the tone mode is selected as follows :

OFF : To listen to a program source without the
↕ tone effect. ("DIRECT" indicator lights up.)
ON : To adjust the tone for your taste.
("DIRECT" indicator goes off.)

■ **When the TONE is set to ON to adjust the tone (bass and treble).**

11. Press the CURSOR UP(▲)/DOWN(▼) buttons to select the desired tone.



- Each time these buttons are pressed, the tone is selected as follows :

→ BASS ↔ TRBL (treble) ↔ TONE ON ←

12. Press the CURSOR LEFT(◀)/RIGHT(▶) buttons to adjust the selected tone as desired.



- The tone level can be adjusted within the range of -10 ~ +10 dB.
- In general, we recommend the bass and treble to be adjusted to 0 dB (flat level).
- Extreme settings at high volume may damage your speakers.
- To complete tone adjustment, repeat the above steps 11 and 12.
- If the tone display disappears, start from the step 9 again.

SURROUND SOUND

• This receiver incorporates a sophisticated Digital Signal Processor that allows you to create optimum sound quality and sound atmosphere in your personal Home Theater.

Surround modes

■ DTS Digital Surround
DTS Digital Surround(also called simply DTS) is a multi-channel digital signal format which can handle higher data rates. Discs bearing the " DIGITAL dts SURROUND " include the recording of

up to 5.1 channels of digital signals, which can be generally thought to provide better sound quality due to the lower audio compression required.
It also provides wide dynamic range and separation, resulting in magnificent sound.

"DTS", and "DTS Digital Surround" are registered trademarks of Digital Theater Systems, Inc.

■ Dolby Digital
Dolby Digital is the multi-channel digital signal format developed by Dolby Laboratories. Discs bearing the " DOLBY DIGITAL " includes the recording of up to 5. 1 channels

of digital signals, which can reproduce much better sound quality, spatial expansion and dynamic range characteristics than the previous Dolby Surround effect.

■ Dolby Pro Logic II surround
This mode applies conventional 2- channel signals such as digital PCM or analog stereo signals as well as Dolby Surround signals, etc. to surround processing to offer improvements over conventional Dolby Pro Logic circuits. Dolby Pro Logic II surround includes 2 modes as follows:

• Dolby Pro Logic II MOVIE
When enjoying movies, this mode allows you to further enhance the cinematic quality by adding processing that emphasizes the sounds of the action special effects.

• Dolby Pro Logic II MUSIC
When listening to music, this mode allows you to further enhance the sound quality by adding processing that emphasizes the musical effects.

■ Dolby Pro Logic
Dolby Pro Logic is a specially encoded two channel surround format which consists of four channels (front left, center, front right and surround). Sources bearing the " DOLBY SURROUND " provide the theater-like surround sound.
The surround channel is monaural, but is played through two surround speakers.

Manufactured under license from Dolby Laboratories.
"Dolby", "Pro Logic", and the double-D symbol are trademarks of Dolby Laboratories.

• The following modes apply conventional 2-channel signals such as digital PCM or analog stereo signals to high performance Digital Signal Processor to recreate sound fields artificially.

■ MATRIX
This mode reproduces a delayed signals from the surround channels to emphasize the sense of expansion for music sources.

■ CHURCH
This mode provides the ambience of a church for baroque, string orchestral or choral group music.

■ THEATER
This mode provides the effect of being in a movie theater when watching a movie source.

■ HALL
This mode provides the ambience of a concert hall for classical music sources such as orchestral, chamber music, or an instrumental solo.

■ STADIUM
This mode provides the expansive sound field to achieve the true stadium effect when watching baseball or soccer games.

• When the EXTERNAL INs are connected to the 6 CH decoder for a surround sound such as Dolby Digital, etc., you can enjoy the corresponding surround sound, too. (For details, see the operator's manual of the component to be connected.)

ENJOYING SURROUND SOUND

■ **Notes**:
- Before surround playback, first perform the speaker setup procedure, etc. on the SETUP menu for optimum performance. (For details, refer to "SETTING THE SPEAKER SETUP" on page 34.)
- When the EXTERNAL IN is selected as an input source, the surround modes cannot be selected.

Depending on how to select a surround mode, select the auto surround mode or the manual surround mode.



• Each time this button is pressed, the mode changes as follows :

Auto surround mode : ("AUTO" indicator lights up.) The optimum surround mode will be automatically selected depending on the signal format being input.

Manual surround mode : ("AUTO" indicator goes off.) You can select the desired of different surround modes selectable for the signal being input with using the MULTI CONTROL konb or the SURROUND MODE UP/DOWN (>/<) buttons.

■ **Notes :**
- When the SPEAKER button is set to off, the auto surround mode is invalid.
- Even when the auto surround mode is selected and the same type of digital signal format is being input, the optimum surround mode may vary depending on whether the speaker type is set to "N (None)" or not.
- When the auto surround mode is selected and the PCM (2 channel) digital signal or the analog stereo signal is being input, only the stereo mode will be selected.
- When the auto surround mode is selected, the surround modes other than the optimum surround mode cannot be selected.
- When 96 kHz PCM signal is being input, only the stereo mode will be selected regardless of selecting either the auto surround mode or the manual surround mode.

■ **When selecting the manual surround mode with pressing the SURROUND MODE button on the front panel.**
Select the desired surround mode.



• Each time the MULTI CONTROL konb is rotated or the SURROUND UP / DOWN (>/<) buttons are pressed, the surround mode changes depending on the input signal format as follows :

Signal format being input	Selectable surround mode
Dolby Digital EX 6.1 channel sources, Dolby Digital 5.1 channel sources	DOLBY DIGITAL
Dolby Digital 2 channel sources	[DOLBY PLII MOVIE, DOLBY PLII MUSIC, DOLBY PRO LOGIC] or <DOLBY DIGITAL>
DTS sources	DTS
PCM (2channel) sources, Analog stereo sources	[DOLBY PLII MOVIE, DOLBY PLII MUSIC, DOLBY PRO LOGIC, MATRIX, CHURCH, THEATER, HALL, STADIUM] or <STEREO>

• Depending on speaker setting, some surround modes can be selected or not as follows :
[ ] : Possible only when "CENTER" or/and "SURR (Surround)" is/are not set to "N (None)".
< > : Possible only when "CENTER" and "SURR (Surround)" are set to "N (None)".

■To cancel the surround mode for stereo operation



- Depending on the signal format which is being input, either the stereo mode or the 2CH downmix mode is selected.
- To cancel either the stereo mode or the 2CH downmix mode, select the surround mode with using the MULTI CONTROL knob on the front panel or the SURROUND MODE UP/ DOWN (＞/＜) buttons on the remote control.

■2CH downmix mode

- This mode allows the multi-channel signals encoded in DTS or Dolby Digital format to be mixed down into 2 front channels and to be reproduced through only two front speakers or through headphones.
- When the SPEAKER button is set to off to listen with headphones while playing the multi-channel digital signals from DTS or Dolby Digital sources, it will enter the 2 CH downmix mode automatically.

When adjusting the sound parameters

- While playing digital signals from Dolby Digital or DTS program source or listening in Dolby Pro Logic II Music mode, you can adjust their parameters for optimum surround effect.

1. Press the SOUND PARAMETER button.



- Then "NIGHT : ~ " (or "PANO : ~ ") is displayed for several seconds.
- If the parameter mode disappears, press this button again.

2. Press the CURSOR UP(▲)/DOWN(▼) buttons to select the desired parameter.



- Each time these buttons are pressed, the parameter mode changes as follows:

→ "NIGHT" ↔ "PANO" ↔ "C.WIDTH" ↔ "DIMEN" ←
(Night mode) (Panorama mode) (Center width control) (Dimension control)

- "NIGHT" can be selected only while playing digital signals from Dolby Digital or DTS source.
- "PANO", "C.WIDTH" and "DIMEN" can be selected only while listening in Dolby Pro Logic II Music mode.

3. Press the CURSOR LEFT(◀)/ RIGHT(▶) buttons to adjust the selected parameter as desired.



■When selecting the "NIGHT (Night mode)"

This function compresses the dynamic range of previously specified parts of Dolby Digital or DTS sound track (with extremely high volume) to minimize the difference in volume between the specified and non-specified parts. This makes it easy to hear all of the sound track when watching movies at night at low levels. The night mode can be set in 11 steps from 0.0 to 1.0 (default value : 0.0).

■Note :

- In some Dolby Digital or DTS softwares, the night mode may not be valid.

Continued

■ **When selecting the "PANO (Panorama)" mode**
This mode extends the front stereo image to include the surround speakers for an exciting "wraparound" effect with side wall imaging. Select "OFF" or "ON"(default value: OFF).

■ **When selecting the "C. WIDTH (Center width)" control**
This adjusts the center image so it may be heard only from the center speaker, only from the left/right speakers as a phantom image, or from all three front speakers to varying degrees.
The control can be set in 8 steps from 0 to 7(default value : 3).

■ **When selecting the "DIMEN (Dimension)" control**
This gradually adjusts the soundfield either towards the front or towards the rear. The control can be set in 7 steps from -3 to +3 (default value : 0).

4. Repeat the above steps 2 and 3 to adjust other parameters.

Adjusting each channel level with test tone

- The volume level of each channel can be adjusted easily with the test tone function.

■ **Note** : When the SPEAKER button is set to off, the test tone function does not work.

1. Enter the test tone mode.





- The test tone mode is displayed and will be heard from the speaker of each channel for 2 seconds as follows:



- When the speaker setting is "N (None or No)", the test tone of the corresponding channel is not available.

2. At each channel, adjust the level as desired until the sound level of each speaker is heard to be equally loud.



- You can select the desired channel with pressing the CONTROL UP(▲)/DOWN(▼) buttons or the CURSOR UP(▲)/DOWN(▼) buttons

3. Cancel the test tone function.



Adjusting the current channel level

- After adjusting each channel level with test tone, adjust the channel levels either according to the program sources or to suit your tastes.
- You can adjust the current channel levels as desired. These adjusted levels are just memorized into user's memory ("CAL"), not into preset memory("REF 1", "REF 2").

1. Press the CHANNEL LEVEL button.





- Then the memory mode ("CAL", etc.) is displayed for several seconds.
- When the memory mode or channel level disappears, press this button again.

2. Select the desired channel.



- Each time these buttons are pressed, the corresponding channel is selected as follows:

→ REF 1, 2 (or CAL) ⟷ FL ⟷ C ⟷ FR ←
→ <DTS or DD > ⟷ SW ⟷ SL ⟷ SR ←

< >: Only when the digital signals from Dolby Digital or DTS program sources are input, these levels can be displayed.

- Depending on the speaker settings ("N (None or No)") and surround mode, etc., some channels cannot be selected.
- When the SPEAKER button is set to off, only the Front Left and Front Right channels can be selected.
- The LFE level (DD and DTS) is applied after exiting the menu.

3. Adjust the level of the selected channel as desired.



- The LFE level can be adjusted within the range of -10~0 dB and other channel levels within the range of -15 ~ +15 dB.
- In general, we recommend the LFE level to be adjusted to 0 dB.(However, the recommended LFE level for some early DTS software is -10 dB.) If the recommended levels seem too high, lower the setting as neccessary.

4. Repeat the above steps 2 and 3 to adjust each channel level.

Memorizing the adjusted channel levels

• You can memorize the adjusted channel levels into preset memory("REF 1", "REF 2") and recall the memorized whenever you want.

1. After performing the steps 1 ~ 4 in "Adjusting the current channel level" procedure on page 20, press the (MEMORY/) ENTER button.





• The "1" of "REF 1" indication flickers for several seconds.

2. Select the desired one of REF 1 and REF 2.



• If the preset memory disappears, perform the above step 1 again.

3. Confirm your selection.



• The adjusted channel levels have now been memorized into the selected memory.

Recalling the memorized channel levels

1. Press the CHANNEL LEVEL button.



• "CAL " (or "REF 1", etc.) is displayed for several seconds.
• If the channel level mode display disappears, press this button again.

2. Select the desired one of REF 1 and REF 2.



• Then the channel levels memorized into the selected preset memory are recalled.

LISTENING TO RADIO BROADCASTS

Auto tuning

1. Select the desired band.





- Each time this button is pressed, the band changes as follows ;

→ FM ST → FM MONO → AM
("ST" lights up) ("ST" goes off)

- When FM stereo broadcasts are poor because of weak broadcast signals, select the FM mono mode to reduce the noise, then FM broadcasts are reproduced in monaural sound.

2. Press the TUNING UP(+)/DOWN(-) butttons for more than 0.5 second.





- The tuner will now search until a station of sufficient strength has been found. The display shows the tuned frequency and "TUNED".
- If the station found is not the desired one, simply repeat this operation.
- Weak stations are skipped during auto tuning.

Manual tuning



- Manual tuning is useful when you already know the frequency of the desired station.
- After selecting the desired band, press the TUNING UP(+) / DOWN(-) buttons repeatedly until the right frequency has been reached.

Auto presetting

- Auto presetting function automatically searches for FM stations only and store them in the memory.
- While listening to radio broadcasts, press and hold down the (MEMORY/) ENTER button for more than 2 seconds.



- Then "AUTO MEM" flickers and this receiver starts auto presetting.
- Up to 30 FM stations can be stored.

■ **Notes**:

- FM stations of weak strength cannot be memorized.
- To memorize AM stations or weak stations, preform "Manual presetting" precedure with using "Manual tuning" operation.

Manual presetting

- You can store up to 30 preferred stations in the memory.

1. Tune in the desired station with auto or manual tuning.

2. Press the (MEMORY/) ENTER button.



- "MEM" is flickering for several seconds.

Continued

3. Select the desired preset number (1~30) and press the (MEMORY/) ENTER button.



- When using the NUMERIC buttons on the remote control.
  Examples) For “3” : (3)
  For “15” : (1) → within 2 seconds → (5)
  For “30” : (3) → within 2 seconds → (0)
- The station has now been stored in the memory.
- When using the NUMERIC buttons, the station is stored automatically without pressing the (MEMORY/)ENTER button.
- A stored frequency is erased from the memory by storing another frequency in its place.
- If “MEM” goes off, start again from the above step 2.

4. Repeat the above steps1 to 3 to memorize other stations.

■MEMORY BACKUP FUNCTION

The following items, set before the receiver is turned off, are memorized.
- INPUT SELECTOR settings
- Surround mode settings
- Preset stations,etc.

Tuning to preset stations

- After selecting the tuner as an input source, select the desired preset number.



- When using the NUMERIC buttons on the remote control.
  Examples) For “3”: (3)
  For “15”: (1) → within 2 seconds → (5)
  For “30”: (3) → within 2 seconds → (0)

Scanning preset stations in sequence



- The receiver will start scanning the stations in the preset sequence and the tuned stations are received for 5 seconds respectively and the other stations are skipped.
- At the desired station, press this button again to stop scanning.

RDS Tuner (Regional Option for some countries in Europe, etc.)

ENGLISH

LISTENING TO RDS BROADCASTS(FM ONLY)

RDS(Radio Data System) is a method for sending information signals together with the transmitter signals. Your tuner is capable of translating these signals and putting the information on the display. These codes contain the following informations. Program Service name (PS), A list of Program Types (PTY), Traffic Announcement (TA), Clock Time (CT), Radio Text (RT).

■ **Note :**

• In the other countries, RDS tuner function cannot be available.

RDS search

• Use this function to automatically search and receive the stations offering RDS services.

1. In the FM mode, select the RDS search mode.



• Each time this button is pressed, the search mode changes as follows;

→ RDS SRCH → TP SRCH → PTY SRCH → OFF

2. When "RDS SRCH" is displayed, press the (MEMORY/) ENTER button.



• The tuner automatically searches stations offering RDS services and the station name is displayed.
• If no RDS station is found, "NO RDS" is displayed.
• When "RDS SRCH" is not displayed, repeat again from the above step 1.

TP search

• Use this function to automatically search and receive the stations broadcasting the traffic program.

1. In the FM mode, press the SEARCH MODE button twice.



• "TP SRCH" is displayed.

2. When "TP SRCH" is displayed, press the (MEMORY/) ENTER button.



• The tuner automatically searches for stations broadcasting the traffic program.
• "NO TRAFF" is displayed if the signal is too weak or there are no stations broadcasting the traffic program.
• When "TP SRCH" is not displayed, repeat again from the above step 1.

PTY search

• Use this function to automatically search and receive the stations broadcasting the desired program type.

1. In the FM mode, press the SEARCH MODE button three times.



PTY SRCH

• "PTY SRCH" is displayed.

2. When "PTY SRCH" is displayed, select the desired program type.



NEWS

• Each time the MULTI CONTROL knob is rotated or the CURSOR LEFT(◀)/RIGHT(▶) buttons are pressed, one of 32 different types of programs is selected.
(NEWS, AFFAIRS, INFO, SPORT, EDUCATE, DRAMA, CULTURE, SCIENCE, VARIED, POP M, ROCK M, EASY M, LIGHT M, CLASSICS, OTHER M, WEATHER, FINANCE, CHILDREN, SOCIAL, RELIGION, PHONE IN, TRAVEL, LEISURE, JAZZ, COUNTRY, NATION M, OLDIES, FOLK M, DOCUMENT, TEST, ALARM, NONE)
• When "PTY SRCH" is not displayed, repeat again from the above step 1.

3. When the desired program is displayed, press the (MEMORY/) ENTER button.



• The tuner automatically searches a station offering PTY services.
• If no station is found, "NO PROG" is displayed.

DISPLAY

In the FM mode,



• Each time this button is pressed, the display mode changes as follows:



• If the signals are too weak or no RDS service is available, "NO NAME", "NO PTY", "NO TIME" or "NO TEXT" will be displayed.

RECORDING

- The analog signals from the EXTERNAL INs as well as the digital signals from the coaxial or optical digital input can be heard but cannot be recorded.
- When recording the analog signals from CD, VIDEO 1~2, be sure to select the analog input. (For details, refer to "When CD, VIDEO 1~2 is selected as an input source" on page 14.)
- The volume and tone (bass, treble) settings have no effect on the recording signals.

Recording with TAPE

1. Select the desired input as a recording source except for TAPE.



2. Start recording on the TAPE.

3. Start play on the desired input.

Dubbing from video components onto VIDEO 1

1. Select the desired of VIDEO 2 ~ 3 as a recording source except VIDEO 1.



2. Start recording on the VIDEO 1.

3. Start play on the desired input.

- The audio and video signals from the desired input will be dubbed onto the VIDEO 1 and you can enjoy them on the TV set and from the speakers.

Dubbing the audio and video signals separately onto VIDEO 1

Example) When dubbing the VIDEO 2 video signal and the CD audio signal separately onto VIDEO 1.

1. Select VIDEO 2 as a video recording source.



2. Select CD as an audio recording source.

3. Start recording on the VIDEO 1.

4. Start play on the VIDEO 2 and the CD respectively.

- The audio signal from the CD and the video signal from the VIDEO 2 will be dubbed and you can enjoy them on the TV set and from the speakers.

■ **Note :** Be sure to observe the order of the above steps 1 and 2.

OTHER FUNCTIONS

Operating the sleep timer

- The sleep timer allows the system to continue to operate for a specified period of time before automatically shutting off.
- To set the receiver to automatically turn off after the specified period of time.

- Each time this button is pressed, the sleep time changes as follows:

→ 10 → 20 → 30 → --- → 90 → OFF
Unit : minutes

- While operating the sleep timer, " ☾ " lights up.
- When the sleep time is selected, all display panels of Sherwood components connected by the DIGI LINK III are dimly lit.

Adjusting the brightness of the fluorescent displays



- Each time this button is pressed, the brightness of all fluorescent displays of Sherwood components connected by the DIGI LINK III changes together as follows:

→ ON → dimmer → OFF

- In the display OFF mode, pressing any button will restore the display ON mode.

Displaying the operation status

During playback,



- Each time this button is pressed, the display mode changes as follows:



- When the EXTERNAL IN is selected as an input source, the surround mode is not displayed.
- When RDS tuner function is available in your country, for details on the FM mode information, see "DISPLAY" on page 25.

System Setup

- The setup menu is displayed on the fluorescent display and allows you to perform the setup procedures easily. In most situations, you will only need to set this once during the installation and layout of your home theater, and it rarely needs to be changed later.
  The setup menu consists of 5 main menus ; system, input, speaker setup, CH level and parameter. These menus are then divided up into various sub-menus.

■ Navigating through the setup menu

- The explanations here assume you are using the buttons on the remote control when performing the setup menu operation. However, you can use the buttons on the front panel as well.
  The buttons on the front panel correspond to those on the remote control as shown below.



1. Turn the setup menu on.



SYSTEM

- The setup menu will be shown.
- To turn the menu off, press this button again.

2. Select the desired menu using the CURSOR UP(▲)/DOWN(▼) buttons.



3. Confirm your selection.



- When selecting "SYSTEM", see "SETTING THE SYSTEM" on page 31.
- When selecting "INPUT", see "SETTING THE INPUT" on page 32.
- When selecting "SPK SET", see "SETTING THE SPEAKER SETUP" on page 34.
- When selecting "CH LEVEL", see "SETTING THE CH LEVEL" on page 38.
- When selecting "PARAMTR", see "SETTING THE PARAMETER" on page 40.
- When selecting "EXIT", the setup menu will be turned off.

■ **Setup menu flow**

• The setup menu flow is as follows :


: Default settings
◆ SYSTEM
SW : NORM / SW +
TONE : OFF / ON
RETURN
BASS 0 / -10 ~ +10
TRBL 0 / -10 ~ +10
RETURN
◆ INPUT
VID 1 CFG
D.IN : OPT / COX1 / COX2 / ANL
AUTO : OFF / ON
RETURN
VID 2 CFG
D.IN : OPT / COX1 / COX2 / ANL
AUTO : OFF / ON
RETURN
CD CFG
D.IN : OPT / COX1 / COX2 / ANL
AUTO : OFF / ON
RETURN
RETURN
◆ SPK SET
CONFIG
FRONT : L / S
CENTER : L / S / N
SURR : L / S / N
SUB-W : Y / N
RETURN
DISTANCE
UNIT : M / FT
FL : 3.0 M / 0.0 ~ 9.0
C : 3.0 M / 0.0 ~ 9.0
FR : 3.0 M / 0.0 ~ 9.0
SR : 1.5 M / 0.0 ~ 9.0
SL : 1.5 M / 0.0 ~ 9.0
SW : 3.0 M / 0.0 ~ 9.0
RETURN
FL : 10 FT / 0 ~ 30
C : 10 FT / 0 ~ 30
FR : 10 FT / 0 ~ 30
SR : 5 FT / 0 ~ 30
SL : 5 FT / 0 ~ 30
SW : 10 FT / 0 ~ 30
RETURN
X-OVER
Fc : 80HZ / 40 ~ 200
RETURN
RETURN
◆ CH LEVEL
MODE : CAL / REF 1 / REF 2
FL 0 dB / -15 ~ +15
C 0 dB / -15 ~ +15
FR 0 dB / -15 ~ +15
SR 0 dB / -15 ~ +15
SL 0 dB / -15 ~ +15
SW 0 dB / -15 ~ +15
DD 0 dB / -10 ~ 0
DTS 0 dB / -10 ~ 0
RETURN
◆ PARAMTR
NIGHT M
NIGHT : 0.0 / 0.0 ~ 1.0
RETURN
PLII MSC
PANO : OFF / ON
C.WIDTH : 3 / 0 ~ 7
DIMEN : 0 / -3 ~ +3
RETURN
RETURN
◆ EXIT

• When "RETURN" is selected on a sub-menu, it will returns to the previous menu.

■ **Note :**

• During setup menu operation, only the (POWER ON/) STANDBY button and the buttons required for system setup will function.

SETTING THE SYSTEM

◆ SYSTEM
- SW : NORM / SW +
- TONE : OFF / ON
  - BASS 0 / -10 ~ +10
  - TRBL 0 / -10 ~ +10
  - RETURN
- RETURN

• SW (SUBWOOFER) : To select the desired subwoofer mode.
• TONE : To adjust the tone (bass and treble) as desired.
• RETURN : To return to the previous menu.

1. Press CURSOR UP(▲)/DOWN(▼) buttons to select the desired item.



2. Press the CURSOR LEFT(◀)/RIGHT(▶) buttons to set the selected item as desired



When selecting the SUBWOOFER mode

• "SW ＋" mode is effective only when "FRONT", "CENTER" or "SURR" is set to "L" and "SUB- W" is set to "Y" on the SPK SET menu. (For details, refer to "SETTING THE SPEAKER SETUP" on page 34.)
• While playing the 2 channel source in MATRIX, CHURCH, THEATER, HALL or STADIUM mode, the low frequency signals can be reproduced from subwoofer regardless of the subwoofer mode setting.

NORM : When the low frequency signals of channels set to "L" are reproduced from those channels only.
In this mode, the low frequency signals that are reproduced from the subwoofer channel is only the low frequency signals of LFE (from the multi-channel sources that contains LFE (Low Frequency Effects) channel, also called the ".1" channel) and the channels set to "S".

SW ＋: When the low frequency signals of channels set to "L" are reproduced simultaneously from those channels and the subwoofer channel.
In this mode, the low frequency range expands more uniformly through the room, but depending on the size and shape of the room, interference may result in a decrease of the actual volume of the low frequency range.

When selecting the TONE

OFF : To listen to a program source without the tone effect. ("DIRECT" indicator lights up.)
↕
ON : To adjust the tone for your taste. ("DIRECT" indicator goes off.)

■ **Note :**

• When the EXTERNAL IN is selected as an input source, the TONE cannot be set to ON.

■ When the TONE is set to ON to adjust the tone (bass and treble)

① Press the CURSOR UP(▲)/DOWN(▼) buttons to select the desired tone.



When selecting the BASS



② Press the CURSOR LEFT(◀)/RIGHT(▶) buttons to adjust the selected tone as desired.



- The tone level can be adjusted within the range of -10 ~ +10 dB.
- In general, we recommend the bass and treble to be adjusted to 0 dB (flat level).
- Extreme settings at high volume may damage your speakers.
- To complete tone adjustment, repeat the above steps ① and ②.

SETTING THE INPUT

◆ INPUT

- VID 1 CFG
  - D.IN : **OPT** / COX1 / COX2 / ANL
  - AUTO : **OFF** / ON
  - RETURN
- VID 2 CFG
  - D.IN : OPT / **COX1** / COX2 / ANL
  - AUTO : **OFF** / ON
  - RETURN
- CD CFG
  - D.IN : OPT / COX1 / **COX2** / ANL
  - AUTO : **OFF** / ON
  - RETURN
- RETURN

• D.IN (DIGITAL IN) : To assign the connected DIGITAL INs to the desired input.
• AUTO (AUTO SURROUND) : To select the auto surround mode or the manual surround mode.
• RETURN : To return to the previous menu.

1. Press the CURSOR UP(▲)/DOWN(▼) buttons to select the desired input source, then press the ENTER button.



Example) When selecting the VIDEO 2



2. Press the CURSOR UP(▲)/DOWN(▼) buttons to select the desired item.



3. Press the CURSOR LEFT(◀)/RIGHT(▶) buttons to set the selected item as desired.



When selecting the DIGITAL IN

- You should assign the connected DIGITAL INs to the desired of CD and VIDEO 1 ~ VIDEO 2. (For details, refer to "CONNECTING DIGITAL INs" on page 6.)
- You can select the desired of OPT (optical), COX 1 (coaxial 1), COX 2 (coaxial 2) and ANL (analog).

■ **Note :**

- In such a case that a DIGITAL IN is assigned to two input sources or more, when these input sources are selected, the digital audio signals can be heard from the same DIGITAL IN.

When selecting the AUTO SURROUND

- Depending on how to select a surround mode, you can select the auto surround mode or the manual surround mode.

OFF (Manual surround mode) : You can select the disired of different surround modes selectable for the signal being input with using the MULTI CONTROL knob or the SURROUND MODE UP/DOWN (>/<) buttons.
↕
(For details, refer to "When selecting the manual surround mode with pressing the SURROUND MODE button on the front panel" on page 17.)

ON (Auto surround mode) : The optimum surround mode will be automatically selected depending on the signal format being input.

■ **Notes :**

- When the SPEAKER button is set to off, the auto surround mode is invalid.
- Even when the auto surround mode is selected and the same type of digital signal format is being input, the optimum surround mode may vary depending on whether the speaker type is set to "N (None)" or not.
- When the auto surround mode is selected and the PCM (2 channel) digital signal or the analog stereo signal is being input, only the stereo mode will be selected.
- When the auto surround mode is selected, the surround modes other than the optimum surround mode cannot be selected.
- When 96 kHz PCM signal is being input, only the stereo mode will be selected regardless of selecting either the auto surround mode or the manual surround mode.

SETTING THE SPEAKER SETUP

- After you have installed this receiver and connected all the components, you should adjust the speaker settings for the optimum sound acoustics according to your environment and speaker layout.
- Even when you change speakers, speaker positions, or the layout of your listening environment, you should adjust the speaker settings, too.


◆ SPK SET
CONFIG
FRONT : L / S
CENTER : L / S / N
SURR : L / S / N
SUB-W : Y / N
RETURN
DISTANCE
UNIT : M / FT
FL : 3.0 M / 0.0 ~ 9.0
C : 3.0 M / 0.0 ~ 9.0
FR : 3.0 M / 0.0 ~ 9.0
SR : 1.5 M / 0.0 ~ 9.0
SL : 1.5 M / 0.0 ~ 9.0
SW : 3.0 M / 0.0 ~ 9.0
RETURN
FL : 10 FT / 0 ~ 30
C : 10 FT / 0 ~ 30
FR : 10 FT / 0 ~ 30
SR : 5 FT / 0 ~ 30
SL : 5 FT / 0 ~ 30
SW : 10 FT / 0 ~ 30
RETURN
X-OVER
Fc : 80HZ / 40 ~ 200
RETURN
RETURN

- CONFIG (CONFIGURATION) : To select the sizes of the speakers that are connected.
- DISTANCE: To enter the distance between the listening position and each speaker to set the delay time automatically for optimum surround playback.
- X-OVER (CROSSOVER) : To select the desired crossover frequency.
- RETURN : To return to the previous menu.

When selecting the CONFIGURATION

1. Press the CURSOR UP(▲)/DOWN(▼) buttons to select the "CONFIG", then press the ENTER button.



2. Press the CURSOR UP(▲)/DOWN(▼) buttons to select the desired speaker.



3. Press the CURSOR LEFT(◀)/ RIGHT(▶) buttons to set the selected speaker as desired.



• Depending on your speaker type, you can select one of these following speaker types.

L(Large): Select this when connecting speakers that can fully reproduce sounds below crossover frequency.

S(Small) : Select this when connecting speakers that can not fully reproduce sounds below crossover frequency. When this is selected, sounds below crossover frequency are sent to the subwoofer or speakers which are set to "L (Large)" (when not using a subwoofer)

N(None): Select this when no speakers are connected. When this is selected, sounds are sent to the speakers which are not set to "N (None)".

Y(Yes)/N(No): Select the desired depending on whether a subwoofer is connected or not.

■**Notes** :

- When speakers are set to "S (Small)", you should set their crossover frequency correctly according to their frequency characteristics. (For details, refer to "When selecting the CROSSOVER" on page 37.)
- When "SUB-W" is set to "N (No)", "FRONT" is automatically set to "L (Large)".
- When the "FRONT" is set to "S (Small)", "CENTER" and "SURR" cannot be set to "L (Large)".

4. Repeat the above steps 2 and 3 until the speakers are all set to the desired mode.

■**About the speaker size**

- Select "L (Large)" or "S (Small)" not according to the actual size of the speaker but according to the speaker's capacity for playing low frequency (bass sound below frequency set on the "X-OVER" menu) signals.
- If you do not know, try comparing the sound at both settings (setting the volume to a level low enough so as not to damage the speakers) to determine the proper setting.

When selecting the DISTANCE

1. Press the CURSOR UP(▲)/DOWN(▼) buttons to select the DISTANCE, then press the ENTER button.



2. Press the CURSOR UP(▲)/DOWN(▼) buttons to select the desired item.



■ **Note :**
- You cannot select the speakers set to "N (None or No)".

3. Press the CURSOR LEFT(◀)/RIGHT(▶) buttons to set the selected item as desired.



■ When selecting the desired unit
- You can select either "M (Meter)" or "FT (Feet)".
- Once a unit is selected, the distances are automatically changed in the selected unit.

■ When setting the distance
- You can set the distance within the range of 0.0 ~ 9.0 meters in 0.3 meter intervals (or 0 ~ 30 feet in 1 feet intervals).

4. Repeat the above steps 2 and 3 until the distances are all set as desired.

■ **About the speaker distance**

When enjoying multi-channel surround playback with Dolby Digital and DTS sources, etc., it is ideal that the center, surround and subwoofer speakers should be the same distance from the main listening position as the front speakers. By entering the distance between the listening position and each speaker, the delay times of center, surround and subwoofer speakers are automatically adjusted to create an ideal listening environment virtually as if the center, surround and subwoofer speakers were at their ideal locations respectively.

When selecting the CROSSOVER

• When speakers are set to "S (Small)", be sure to set their crossover frequency correctly according to their frequency characteristics.

1. Press the CURSOR UP(▲)/DOWN(▼) buttons to select the "X-OVER", then press the ENTER button.



2. Press the CURSOR LEFT(◀)/RIGHT(▶) buttons to set the crossover frequency as desired.



• You can adjust the crossover frequency within the range of 40 ~ 200 Hz in 10 Hz intervals.

■About the crossover frequency

• When speakers are set to "S (Small)", low frequencies in those channels that are below the crossover frequency are to output from subwoofer or front speakers which are set to "L (Large)" (when not using a subwoofer).

• Refer to the operating instructions of the speakers to be connected. If the frequency range of your speaker is 100 Hz~20 kHz, the crossover frequency should be set to 100 Hz(or slightly higher).

SETTING THE CH LEVEL

◆ CH LEVEL —— MODE : CAL / REF 1 / REF 2

	CAL	REF 1	REF 2
FL	0 dB / -15 ~ +15	0 dB / -15 ~ +15	0 dB / -15 ~ +15
C	0 dB / -15 ~ +15	0 dB / -15 ~ +15	0 dB / -15 ~ +15
FR	0 dB / -15 ~ +15	0 dB / -15 ~ +15	0 dB / -15 ~ +15
SR	0 dB / -15 ~ +15	0 dB / -15 ~ +15	0 dB / -15 ~ +15
SL	0 dB / -15 ~ +15	0 dB / -15 ~ +15	0 dB / -15 ~ +15
SW	0 dB / -15 ~ +15	0 dB / -15 ~ +15	0 dB / -15 ~ +15
DD	0 dB / -10 ~ 0	0 dB / -10 ~ 0	0 dB / -10 ~ 0
DTS	0 dB / -10 ~ 0	0 dB / -10 ~ 0	0 dB / -10 ~ 0
RETURN			

■ **Note :**
• Depending on the speaker settings ("N (None or No)"), some channels cannot be selected.

Adjusting the current channel level

• You can adjust the current channel levels as desired. These adjusted levels are just memorized into user's memory("CAL"), not into preset memory ("REF 1", "REF 2")
• After adjusting each channel level with test tone, adjust the channel levels either according to the program sources or to suit your tastes. (For details, refer to "Adjusting each channel level with test tone" on page 19.)

1. Press the CURSOR UP(▲)/DOWN(▼) buttons to select the desired channel.



Example) When selecting Dolby Digital source's LFE



2. Press the CURSOR LEFT(◀)/RIGHT(▶) buttons to adjust the level of the selected channel or program source's LFE as desired.



• The LFE level can be adjusted within the range of -10 ~ 0 dB and other channel levels within the range of -15 ~ +15 dB
• In general, we recommend the LFE level to be adjusted to 0 dB.(However, the recommended LFE level for some early DTS software is -10 dB.) If the recommended levels seem too high, lower setting as necessary.

3. Repeat the above steps 1 and 2 to adjust each channel level.

Memorizing the adjusted channel levels

• You can memorize the adjusted channel levels into preset memory("REF 1", "REF 2") and recall the memorized whenever you want.

1. After performing the steps 1 ~ 3 in "Adjusting the current channel level" procedure on page 38, press the ENTER button.





• The "1" of "REF 1" indication flickers.

2. Press the CURSOR LEFT(◀)/RIGHT(▶) buttons to select the desired preset memory, then press the ENTER button.



• Each time the CURSOR LEFT(◀) or RIGHT(▶) button is pressed, "REF 1" or "REF 2" is selected.
• The adjusted channel levels have now been memorized into the selected memory.

Recalling the memorized channel levels

1. Press the CURSOR UP(▲)/DOWN(▼) buttons to select the "MODE ~ ".





• "CAL" may be displayed instead of "REF 1" or "REF 2".

2. Press the CURSOR LEFT(◀)/RIGHT(▶) buttons to select the desired one of REF 1 and REF 2.



• Then the channel levels memorized into the selected preset memory are recalled.

SETTING THE PARAMETER

◆ PARAMTR
- NIGHT M
  - NIGHT : 0.0 / 0.0 ~ 1.0
  - RETURN
- PLII MSC
  - PANO : OFF / ON
  - C.WIDTH : 3 / 0 ~ 7
  - DIMEN : 0 / -3 ~ +3
  - RETURN
- RETURN

• NIGHT M (NIGHT MODE) : To adjust the dynamic range compression that makes faint sound easier to hear at low volume levels.
• PLII MSC (DOLBY PLII MUSIC) : To adjust the various surround parameters for optimum surround effect.
• RETURN : To return to the previous menu.

When selecting the NIGHT MODE

• This function compresses the dynamic range of previously specified parts of Dolby Digital or DTS sound track (with extremely high volume) to minimize the difference in volume between the specified and non-specified parts.
This makes it easy to hear all of the sound track when watching movies at night at low levels.

■ **Notes:**
• The night mode setting is valid only when the digital signals from Dolby Digital or DTS program source are being input.
• In some Dolby Digital or DTS softwares, the night mode setting may not be valid.

1. Press the CURSOR UP(▲)/DOWN(▼) buttons to select the "NIGHT M", then press the ENTER button.



2. Press the CURSOR LEFT(◀)/ RIGHT(▶) buttons to adjust the dynamic range compression as desired.



0.0 ↕ 0.1 ↕ 0.2 : : : 0.9 ↕ 1.0

Lower compression

Higher compression

When selecting the DOLBY PLII MUSIC

• You can adjust the various surround parameters for optimum surround effect.

■**Note:**

• The parameter settings are valid only when listening in Dolby Pro Logic II Music mode.

1. Press the CURSOR UP(▲)/DOWN(▼) buttons to select the "PLII MSC", then press the ENTER button.



2. Press the CURSOR UP(▲)/DOWN(▼) buttons to select the desired parameter.



3. Press the CURSOR LEFT(◀)/ RIGHT(▶) buttons to adjust the selected parameter as desired.



■**When selecting the "PANO (Panorama)" mode**
This mode extends the front stereo image to include the surround speakers for an exciting "wraparound" effect with side wall imaging. Select "OFF" or "ON"(default value:OFF).

■**When selecting the "C. WIDTH (Center width)" control**
This adjusts the center image so it may be heard only from the center speaker, only from the left/right speakers as a phantom image, or from all three front speakers to varying degrees. The control can be set in 8 steps from 0 to 7 (default value : 3).

■**When selecting the "DIMEN (Dimension)" control**
This gradually adjusts the soundfield either towards the front or towards the rear. The control can be set in 7 steps from -3 to +3 (default value : 0).

4. Repeat the above steps 2 and 3 to adjust other parameters.

Troubleshooting Guide

If a fault occurs, run through the table below before taking your receiver for repair.
If the fault persists, attempt to solve it by switching the receiver off and on again. If this fails to resolve the situation, consult your dealer. Under no circumstances should you attempt to repair the receiver yourself. This could void the warranty.

PROBLEM	POSSIBLE CAUSE	REMEDY
No power	• The AC input cord is disconnected. • Poor connection at AC wall outlet or the outlet is inactive.	• Connect the cord securely. • Check the outlet using a lamp or another appliance.
No sound	• The speaker cords are disconnected. • The master volume is adjusted too low. • The MUTE button on the remote control is pressed to ON. • Speakers are not switched on. • Incorrect selection of the input source. • Incorrect connections between the components.	• Check the speaker connections. • Adjust the master volume. • Press the MUTE button to cancel the muting effect. • Press the SPEAKER button to ON. • Select the desired input source correctly. • Make connections correctly.
No sound from the surround speakers	• Surround mode is switched off(stereo mode). • Master volume and surround level are too low. • A monaural source is used. • Surround speaker setting is “N”.	• Select a surround mode. • Adjust master volume and surround level. • Select a stereo or surround source. • Select the desired surround speaker setting.
No sound from the center speaker	• Surround mode is switched off(stereo mode). • Center speaker setting is “N”. • Master volume and center level are too low.	• Select the desired surround. • Select the desired center speaker setting. • Adjust master volume and center level.
Stations cannot be received	• No antenna is connected. • The desired station frequency is not tuned in. • The antenna is in wrong position.	• Connect an antenna. • Tune in the desired station frequency. • Move the antenna and retry tuning.
Preset stations cannot be received	• An incorrect station frequency has been memorized. • The memorized stations are cleared.	• Memorize the correct station frequency. • Memorize the stations again.
Poor FM reception	• No antenna is connected. • The antenna is not positioned for the best reception.	• Connect an antenna. • Change the position of the antenna.
Continuous hissing noise during FM reception, especially when a stereo broadcast is received.	• Weak signals.	• Change the position of the antenna. • Install an outdoor FM antenna.
Continuous or intermittent hissing noise during AM reception, especially at night.	• Noise is caused by motors, fluorescent lamps or lightning, etc.	• Keep the receiver away from noise sources. • Install an outdoor AM antenna.
Remote control unit does not operate.	• Batteries are not loaded or exhausted. • The remote sensor is obstructed.	• Replace the batteries. • Remove the obstacle.

Specifications

■ AMPLIFIER SECTION

- Power output, stereo mode, 6 Ω, THD 0.7%, 40 Hz~20 kHz ..... **2 × 100 W**
- Total harmonic distortion, 6 Ω, 100 W, 1 kHz ..... **0.09 %**
- Intermodulation distortion
  60 Hz : 7 kHz= 4 : 1 SMPTE, 6 Ω, 100 W ..... **0.1 %**
- Input sensitivity, 47 kΩ
  Line (CD, TAPE, VIDEO) ..... **280 mV**
- Signal to noise ratio, IHF “A” weighted
  Line (CD, TAPE, VIDEO) ..... **92 dB**
- Frequency response
  Line (CD, TAPE, VIDEO), 20 Hz~50 kHz ..... **+0 dB, -3 dB**
- Output level
  TAPE REC, 2.2 kΩ ..... **280 mV**
  PRE OUT (Subwoofer), 1 kΩ ..... **1.0 V**
- Bass/Treble control, 100 Hz/10 kHz ..... **±10 dB**
- Surround mode, only channel driven
  Front power output, 6 Ω, 1 kHz, THD 0.7 % ..... **125 W / 125 W**
  Center power output, 6 Ω, 1 kHz, THD 0.7 % ..... **125 W**
  Surround power output, 6 Ω, 1 kHz, THD 0.7 % ..... **125 W / 125 W**

■ DIGITAL AUDIO SECTION

- Sampling frequency ..... **32, 44.1, 48, 96 kHz**
- Digital input level
  Coaxial, 75 Ω ..... **0.5 Vp-p**
  Optical, 660 nm ..... **-15~-21 dBm**

■ VIDEO SECTION

- Video format ..... **PAL**
- Input sensitivity (=Output level) , 75 Ω
  Video (Composite (normal)) ..... **1 Vp-p**

■ FM TUNER SECTION

- Tuning frequency range ..... **87.5~108 MHz**
- Usable sensitivity, THD 3%, S/N 30 dB ..... **12.8 dBf**
- 46 dB quieting sensitivity, mono/stereo ..... **20.2 / 45.3 dBf**
- Signal to noise ratio, 65 dBf, mono/stereo ..... **55 / 50 dB**
- Total harmonic distortion, 65 dBf,1 kHz, mono/stereo ..... **0.5 / 1.0 %**
- Frequency response, 30 Hz~12 kHz ..... **±3.0 dB**
- Stereo separation, 1 kHz ..... **30 dB**
- Capture ratio ..... **4 dB**
- IF rejection ratio ..... **80 dB**

■ AM TUNER SECTION

- Tuning frequency range ..... **522~1611 kHz**
- Usable sensitivity ..... **500 µV/m**
- Signal to noise ratio ..... **40 dB**
- Selectivity ..... **25 dB**

■ GENERAL

- Power supply ..... **230 V ~ 50 Hz**
- Power consumption ..... **330 W**
- Switched AC outlet ..... **Total 100 W (0.43A) max.**
- Dimensions (W × H × D, including protruding parts) ..... **440 × 141 × 365 mm (17-3/8 × 5-1/2 × 14-3/8 inches)**
- Weight (Net) ..... **9.5 kg (20.9 lbs)**

Note: Design and specifications are subject to change without notice for improvements.